

Prod Code	Description
Optional Fujimoto SHP5080 Accessories	
886511	Fujimoto SHP5080 Spare Parts Kit (consumable parts - Bushings, E- and C-Rings, Roller Springs, Knock Pins, Squeegee Roller Springs, Drive Gears, Main Gears, Chemical Filters & Fuses)
886512	Paper Magazine (spare)
Digital RA Pro Mixers	
886730	2 Solution Digital RA Pro Mixer (without stand)
886731	Digital RA Pro Mixer Stand (for 2 or 3 Solution Digital RA Pro Mixer)
886733	3rd Solution Add-On to 2 Solution Digital RA Pro Mixer #886730. Must order 1 #886730 for every 886733 required.
886734	Wall Mount Framework for #886733 3rd Solution Add-On (order only if mixer will be wall mounted and not mounted on stand #886731).
Fotoba Cutters	
886515	Digitrim 20TT
886516	Digitrim 20TT Roll Accessory
886517	Digitrim 30
886518	Digitrim 30 Stand
886519	Digitrim 30 Roll Accessory for Stand 30
886520	Digitrim 62
886521	Digitrim 62 Stand
886522	Digitrim 62 Roll Accessory for Stand 62
Other Very High Volume Fotoba Cutter Products	
886354	XY Auto Digitrim 20
886523	XY Auto Digitrim 32 RS
886524	X/Y Sorter 100
886525	XY Auto Digitrim 32
886526	X/Y Sorter 150
886527	X/Y Server (Workflow Organizer)
Optional Fotoba Cutter Enterprise/Network Software (cutter ships with basic software)	
886528	Trim Manager (Raster Version - one install seat already included with each cutter)
886529	Trim Manager (Postscript Version)
886530	Tiling Module
Fujimoto Parts	
886001	Print Roller Bottom
886002	Print Roller Upper
886003	Convey Roller 1
886004	Convey Roller 2
886005	Convey Roller 3
886006	Roller (A) Bottom
886007	Roller (B) Upper
886008	Filter Case, Main Body
886009	Drive Gear (25), Top Roller
886010	Drive Gear (42), Elevator Unit
886011	IG A (30), Elevator Unit
886012	IG B (30), Elevator Unit
886013	Bottom R Dive G, Elevator Unit
886014	Operation Gear G, Elevator Unit
886015	RD Gear (40), Paper Processor
886016	Drive Gear (60), Paper Processor
886017	Roller Pulley (1), Bottom Roller

886018	Roller Pulley (2), Bottom Roller
886019	Idling Pulley (1), Bottom Roller
886020	Idling Pulley (2), Bottom Roller
886021	Motor Pulley, Bottom Roller
886022	Boss
886023	Main Gear
886024	Press Roller Bush
886025	Knock Pin
886130	Crank Gear (B)
886133	Crank (B)
886134	Boss (10)
886136	Gear S2
886137	Washer (8)
886140	Timing Pulley (6,4)
886141	Timing Pulley (22A)
886143	Worm Gear POM
886026	Press Roller Spring
886027	Squeeze Roller Spring B
886028	Balancer Assembly
886144	Sponge W15XT10XL780
886148	Sponge W15XT10XL1207
886150	Sponge W15XT10XL800
886217	Sponge W15XT10XL1000
886218	Intake Filter
886029	Flat Belt
886030	Flat Belt
886031	Friction Clutch
886032	Bearing
886033	Bearing
886034	Miniature Bearing 8
886035	Miniature Bearing 8
886036	Miniature Bearing 10
886037	Idling Gear 60
886038	Idling Gear 80
886039	Idling Gear 72
886040	Oilless Brush 6
886041	Oilless Brush 6
886042	Oilless Brush 8
886043	Oilless Brush 8
886044	Oilless Brush 5
886045	Polislider 8
886046	One Way Bearing
886047	Timing Belt 70
886048	Timing Belt 110
886049	Timing Belt 85
886050	Idle Gear 30
886051	Polislider 10
886052	Lock Spring
886053	Top Roller Press Spring
886054	Roller Press Spring, Paper Processor Unit
886055	Press Unit Spring
886101	Upper Load Motor Assembly

886102	Print Motor Assembly
886103	Upper Cutter Assembly
886104	Up/Down Motor Assembly
886105	Press Motor Assembly
886106	Accumulator Motor Assembly
886107	Load_Out Motor 1 Assembly
886108	Load_Out Motor 2 Assembly
886109	Clutch Assembly
886110	MD925 Fan Assembly
886111	MD 625 Fan Assembly
886112	MD825 Fan Assembly
886113	Upper Paper Set Position Sensor Assembly
886114	Paper Load Sensor Assembly
886115	Press Motor Home Position Sensor Assembly
886116	Upper Magazine Set Switch Assembly
886117	Upper Paper Reverse Switch Assembly
886118	Lower Paper Reverse Switch Assembly
886119	24V / 500W Power Supply
886120	5V / 15W Power Supply
886121	24V / 250W Power Supply
886122	5V / 30W Power Supply
886219	Fuse 0.5A
886220	Fuse 1.0A
886221	Fuse 1.6A
886222	Fuse 2.0A
886223	Fuse 3.0A
886123	M-Sensor PCB
886124	Entrance PCB
886125	D-Drive PCB
886126	S-Drive PCB
886127	IO PCB
886128	MPU PCB ver. 00.00.11a (2004.04.28)
886129	Bush
886131	Bush (A)
886132	Main Gear
886135	Drive Gear
886138	Idle Gear
886139	Knock Pin (1)
886142	Roller Spring (Stainless)
886145	Roller Spring (Hastelloy)
886146	Squeeze Roller Spring B
886147	Drive Roller (2)51L-1
886149	Drive Rubber Roller (51)-1
886151	Squeeze Roller Bottom 1
886152	1st Rack Cushion Roller Shaft
886153	Cushion Roller Shaft
886224	E-Ring
886225	C-Ring
886154	Cross Over Cover
886155	Sponge Roller 1
886156	Dryer Roller 1
886157	Bush (POM)

886158	Dryer Squeeze Roller 1
886159	Bearing
886160	Miniature Bearing
886161	Miniature Bearing
886162	RS Roller Chain 1
886163	RS Roller Chain 2
886164	Accumulator Roller Spring
886165	Filter Case
886166	Filter Case Cap
886167	Worm Gear
886168	Worm Gear (POM)
886169	O Ring
886170	Chemical Filter
886171	CD Rack Assembly
886172	BF Rack Assembly
886173	W1 Rack Assembly
886174	W2 Rack Assembly
886175	W3 Rack Assembly
886176	Entrance Rack Assembly
886177	Cross Over Guide Assembly
886178	Control Strip Holder Assembly
886179	Time Switch
886180	Solid State Relay 40A
886181	Motor PCB
886182	DC24V / 150W Power Supply
886183	DC5V / 30W Power Supply
886184	Cooling Fan Assembly
886185	Display Relay PCB
886186	Display PCB
886187	Dryer PCB
886188	Rep. PCB
886189	Watch Dog Timer PCB
886190	Solid State Relay 20A
886191	Heater Assembly with Thermostat
886192	Thermostat
886193	CD Circulation Pump Assembly
886194	Circulation Pump Assembly
886195	Thermister Assembly
886196	Motor with Drive PCB
886197	Gear Head
886198	Rep. Pump Assembly
886199	Exhaust Fan 24 Assembly
886200	Exhaust Fan 200 Assembly
886201	Entrance Sensor Assembly
886202	Dryer Heater
886203	Dryer Fan
886204	Dryer Thermostat
886205	Dryer Thermister
886206	Exit Sensor
886207	Fuse 6A / 250V
886208	Fuse 4A / 250V
886209	Fuse 2A / 125V

886210	Fuse 1A / 250V
886211	IOM2 PCB
886212	I/O PCB
886213	SSR PCB
886214	A/D PCB
886215	Analog PCB (for Bath)
886216	Analog PCB (for Dryer)