

NEGACOLOR™ N1-S Developer Starter

For Processing C-41 and Compatible Color Negative Films



Catalog Number: 600005425 (2 x 1L)

DESCRIPTION

This product is a C-41 developer starter used for mixing a fresh working tank solution of CN16L N1-R VLR NEGACOLOR™ Developer, CN16 N1-R NEGACOLOR™ Developer, or CN16 N1-MV Developer.

SAFE HANDLING INSTRUCTIONS

Please refer to Material Safety Data Sheets (MSDS) for specific chemical details. For emergencies, please contact CHEMTREC at 1-800-424-9300. You can obtain an MSDS by calling the Fujifilm Technical Hotline at 1-800-526-0851 Ext. 10.

HMIS INFORMATION

Hazardous Materials Identification System. Please refer to Section 3 in the MSDS for further information.

	Concentrate
Health	1
Flammability	0
Reactivity	0
Personal Protection	C

WORKING TANK MIX INSTRUCTIONS USING: EC¹ NEGACOLOR™ LR Developer Replenisher

W	Warm Water	Starter	EC ¹ NEGACOLOR™ LR Developer Replenisher
1 Liter	225 ml	25 ml	750 ml
1 Gallon	28.8 oz	3.2 oz	96 oz
Tank Volume			
YOUR TANK			

IMPORTANT: Tablets in freshly mixed replenisher **MUST** be fully dissolved, and the replenisher re-mixed after dissolution, before fresh replenisher can be used to mix a fresh working tank solution.

WORKING TANK MIX INSTRUCTIONS USING: NEGACOLOR™ Developer Replenisher

W	Warm Water	Starter	NEGACOLOR™ Developer Replenisher
1 Liter	137.5 ml	12.5 ml	850 ml
1 Gallon	17.6 oz	1.6 oz	108.8 oz
Tank Volume			
YOUR TANK			

WORKING TANK MIX INSTRUCTIONS USING: NEGACOLOR™ LR Developer Replenisher

W	Warm Water	Starter	NEGACOLOR™ LR Developer Replenisher
1 Liter	225 ml	25 ml	750 ml
1 Gallon	28.8 oz	3.2 oz	96 oz
Tank Volume			
YOUR TANK			

To figure out the amount of water, starter, and developer replenisher that you will need, multiply your tank volume by each of the numbers listed, in either liters or gallons. For example, if you have a 10 liter tank, 10x225 ml = 2.25 liters of water, 10x25 ml = 250 ml of developer starter and 10x750 ml = 7.5 liters of developer replenisher.

1000ml = 1 liter 128 oz = 1 gallon

SHELF LIFE

	Concentrate
Time	U = 36 Months O = 12 Months
Color	Clear, Colorless
Odor	No Odor

U = Unopened, O = Opened

